


DIALLER OPERATION



CENTRAL STATION MONITORING

The dialler sends alarm reports to a central station using Central Station Telephone numbers 1 and 2, (P70E & P71E, Page 36).

It is not necessary to program a reporting format. Alarm reports are automatically sent in Contact ID format to the telephone numbers programmed at P70E and/or P71E.

Events are reported to the central station using the Contact ID format as follows:

SSSS 18 Q XYZ GG CCC E

SSSS18 = Client Account Number + Contact ID identifier.

Q = Event qualifier (1 = New Event, 3 = Restore).

XYZ = Event code.

GG = Group Number (always 00).

CCC = Qualifier (0-9) + User ID (uu) / Zone ID (zz), or Unique Code (030-099)

E = Checksum.

RESTORAL REPORTS

Restores are always sent for the following alarms when the device alarm condition is physically removed:
 137 Siren box tamper
 302 Panel low battery
 383 Tamper (Detector)
 381 Radio device supervision poll fail

Restores are always sent for the following alarms on disarming when a valid code is entered, (if Restores are enabled):
 101 Radio Key Medical alarm
 120 Panic alarm
 121 Duress alarm
 130 Burglary alarm
 133 24 hour alarm
 355 Radio jamming alarm

REPORT NAME	CONTACT ID CODE			REPORTED IN VOICE FORMAT
	Q	XYZ	CCC	
Zone Alarm	q	130	0zz	Yes
Zone 24 Hour Alarm	q	133	0zz	Yes
Keypad Panic	q	120	032	Yes
Keypad/Radio Key Duress	q	121	1uu	Yes
Keypad Medical	q	100	033	Yes
Keypad Fire	q	110	034	Yes
Radio Key Panic	q	120	1uu	Yes
Radio Key Medical	q	101	1uu	Yes
Radio Detector Supervision	q	381	4zz	
Radio Panic Button Supervision	q	381	1uu	
Radio Jamming or Substitution	q	355	060	
Panel/Siren Tamper	q	137	040	Yes
Keypad Tamper	q	137	042	Yes
Radio Sensor Tamper	q	383	3zz	Yes
Mains Fail	q	301	050	
Panel Battery Low	q	302	052	
Radio Detector Battery Low	q	384	3zz	
Open/Disarm	1	401	0uu	
Close/Arm	3	401	0uu	
Shorcut Arm (ARM + E)	3	401	025	
Cancel/Disarm	1	406	0uu	
Zone Manual Exclude	q	573	0zz	
Zone Auto Exclude	q	380	0zz	
Exit Install mode	1	306	035	
Test Report	1	602	063	