



How to create Raid 5 array in 96NI-RT series NVR


Step 1: Click Menu>HDD




Step 2: Click **RAID** > **Physical Disk**, select disks (No. 2, 4, 5) and then click **Create**.




Step 3: Select **RAID Level RAID 5** and then click **OK**.



Step 4: Click **Array>Create Vd.**




Step 5: Input **Name** and **Capacity** of virtual disk.





Step 6: Click **General**> **HDD information**, select the HDD and initialize it.



HDD

General > HDD Information

Advanced

RAID

<input type="checkbox"/> L...	Capacity	Status	Property	Type	Free Space	Gr...	Edit	D...
<input type="checkbox"/> 1	1,000GB	Normal	R/W	Array	999GB	1	-	-
<input type="checkbox"/> 17	0MB	Offline	R/W	NAS	0MB	1		

Total Capacity: 0MB

Free Space: 0MB

Live View

Expand Add Init Back

First Choice for Security Professionals
Hikvision Technical Support